▲ PEAKTRONICS

Cycle Timers and Sequence Timers



RCT-101 RCT-101A RCT-101B



Arran Arrange

DST-100 DST-100A

AST-100 AST-100A

AST-100B

AC Repeat Cycle Timers

The **RCT Series** Repeat Cycle Timers are used to lengthen the time an actuator requires to move from one extreme to the other by cycling the actuator on and off; the on and off times are adjustable. The simple 2-wire connection allows the unit to be easily installed by connecting it in series with one of the motor wires and can be used with or without a positioner. The unit can be wired to lengthen the open time only, the close time only, or both. Different times for open and close can be achieved by installing two units.

Voltage	Model	List
117VAC	RCT-101	\$ Call
234VAC	RCT-101A	\$ Call
24VAC	RCT-101B	\$ Call

AC Sequence Timer

The **AST-100** AC Sequence Timer is used to control the open and closed times of AC actuators (up to 2A). The open time can be set from 10 to 1270 seconds (in 10 second increments), or from 1 to 127 minutes (in 1 minute increments). The total interval time can be set from 5 to 2555 minutes (in 5 minute increments), or from 0.5 to 255.5 hours (in 0.5 hour increments).

Voltage	Model	List
117VAC	AST-100	\$ Call
234VAC	AST-100A	\$ Call
24VAC	AST-100B	\$ Call

DC Sequence Timer

The **DST-100** DC Sequence Timer is used to control the open and closed times of 12VDC or 24VDC actuators (up to 5A locked rotor current). Its low operating current (typically 100uA) makes it suitable for battery operated applications, and its compact size allows it to be mounted inside most actuators. The open time can be set from 16 to 4080 seconds (in 16 second increments), and the total interval time can be set from 5 to 9995 minutes (in 5 minute increments).

1	Voltage	Model	List
	10-16VDC	DST-100	\$ Call
	20-30VDC	DST-100A	\$ Call

Mounting Hardware

Model	Description	List
MTB-102	General purpose mounting bracket for RCT Series	\$ Call
MTB-103	Mounting Bracket: mounts RCT Series in HQ-015,-020,-030,- 050,-060,-080,-120,-200,-300	\$ Call
MTB-104	Mounting Bracket: mounts RCT Series in I-Tork ITQ-0160 to ITQ-3000	\$ Call

www.peaktronics.com